

USAGE:

1. Connect the DB25 port the cable to your printer.
2. Turn on the printer's power and insert the other end of the cable into the USB port. The WINDOWS SYSTEM will inform you that your computer has found a new hardware. WINDOWS 98se/ME/2000/XP/Vista system, system will automatically find and recognize the driver, then inform you that it has found the printer and the automatically setting up will go on immediately.
3. If using older version of 98/ME point the the installation to the DRIVER/WIN98 file (or WinME accordingly). The computer will inform that it has found the printer and will set up the compatible driver immediately.

NOTE:

If the computer is unable to locate/print to your printer you may need to:

Install the printer drivers prior to installing the cable.

Change the printer port from parallel/LPT to USB

Enable "USB printing support" in the Windows device manager

